

5 DIGITAL DUAL INPUT MICRO-PROCESS MATH FUNCTION ISOLATED TRANSMITTER

ATM-M

FEATURES

- Accuracy: $\pm 0.1\%$ F.S.
- Mathematic function available: $A \pm B$, $A \times B$, A / B , $A \& B$ (Hi or Lo), $|A|$, $\sqrt{A}$
- High brightness 0.4" LED display range: -19999~99999; decimal point selectable
- Display range programmable
- Surge test of AC 2000V / min between input / output / power
- High stability, non-flammable case (PC), high safety




ORDER INFORMATION: ATM - M - [Code 1] [Code 2] [Code 3] - [Code 4] - [Code 5]

Code 1	Input Type	Code 2	I/P A	Code 3	I/P B	Code 4	Aux. Power	Code 5	Analog Output
D	DC	1	0~50mV	1	0~50mV	A	AC/DC 100~240V	1	4~20mA
A	AC A/VG	2	0~10V	2	0~10V	D	AC/DC 22~60V	2	0~20mA
M	AC TRMS	3	0~300V	3	0~300V	O	Option	3	0~5V
		4	0~20mA	4	0~20mA			4	0~10V
		5	4~20mA	5	4~20mA			L	LoopPower: 15~30 Vdc 4~20 mA
		0	Option	0	Option			O	Option


SPECIFICATION

- ◆ Accuracy: $\pm 0.1\%$ F.S.
- ◆ Display Screen: High brightness red LED; 10.16mm (0.4")
- ◆ Display Range: -19999~99999
- ◆ Zero Adjustment: ± 9999
- ◆ Span Adjustment: ± 9999
- ◆ Over Range Indication: doFL / ioFL or -doFL / -ioFL
- ◆ Polarity Indication: Automatic with "-" indication
- ◆ Parameters Setting: Push buttons
- ◆ Back Up Memory: EEPROM
- ◆ Analog Output Resolution: 15 bit
- ◆ Output Response Time: <250 msec (0~90%)
- ◆ Output Capability: Voltage Output: <20mA
Current Output: <10V
- ◆ Output Ripple: $\leq \pm 0.1\%$ F.S.
- ◆ Isolation: Input / Output / Power / Case
- ◆ Temperature Coefficient: 100ppm / °C (0~60°C)
- ◆ Operating Temperature: 0~60°C
- ◆ Operating Humidity: 20~90% RH (non-condensing)
- ◆ Storage Temperature: -10~70°C
- ◆ Storage Humidity: 20~90% RH (non-condensing)
- ◆ Power Supply: AC/DC 100~240V; AC/DC 22~60V
- ◆ Surge Test: 2kVac / 1min
- ◆ Insulation Resistance: >100M Ω with 500Vdc
- ◆ Input Impedence: Voltage: >2V for 20K Ω / V; $\leq 2V$ for >200M Ω
Current: $\geq 0.2A$ at 100mV; <0.2A at 1V
- ◆ Installation: Socket / Plug in


FRONT PANEL & KEY FUNCTIONS



DIMENSION




WIRING CONNECTION



* Please understand key indicators & functions at the first operation.

FRONT PANEL & KEY FUNCTIONS



Key Name	Symbol	Descriptions
Reset Key		1. Press this key to enable the reset function & reset indicator (Z) is light; press this key again to disable the reset function & reset indicator (Z) is dark.
Enter Key & Save Key	ENT	1. In the measuring status, press this key can enter to parameter pages. 2. In the parameter setting, press this key can save the value & go to next parameter.
Shift Key		1. In the parameter setting, press this key can move the cursor left.
Up Key & Display Value Adjusting Key		1. In the measuring status, press this key for 3 sec can enter to display adjustment of "ZERO" & "SPAN" 2. In the parameter setting, press this key can increase the digits.
Down Key & A/O Adjusting Key		1. In the measuring status, press this key for 3 sec can enter to analog output adjustment. 2. In the parameter setting, press this key can decrease the digits.

- **1. The following block charts are parameters codes, parameter codes & parameters will alternate flashing if the parameters can be modified.
2. To modify the parameters, please press , and press **ENT** to save the parameters after the modification.
3. Please don't forget the new pass code after modification.
4. In any pages, press & , or don't press any keys for 2 minutes that will back to measuring status.

GENERAL MODE OPERATING PROCEDURES

Block Charts	Display	Descriptions	Default
Power On		Display: "ZERO" & "SPAN" Adjustment	
	Measuring Status	Present value for measurement.	
	Display (dZEro) Adjustment (dZEro)	Press to select adjusting speed rate, press to modify the zero value. PS: To use this function to adjust the real zero value.	00000
	Display Span Adjustment (dSPAN)	Press to select adjusting speed rate, press to modify the span value. PS: To use this function to adjust the real span value.	00000
		Analog Output: "ZERO" & "SPAN" Adjustment	
	Measuring Status	Present value for measurement.	
	A/O Zero Adjustment (AZEro)	Press to select adjusting speed rate, press to modify the A/O zero. PS: To use this function to adjust the real A/O zero.	00000
	A/O Span Adjustment (ASPAn)	Press to select adjusting speed rate, press to modify the A/O span. PS: To use this function to adjust the real A/O span.	00000

		Display Value: Preview Input A & Input B	
	Measuring Status	Present value for measurement.	
	Preview Input A Display Value (A CH.)	Press $\triangleleft \triangle \triangleright$ to show the current input A display value.	Input A Display Value
	Preview Input B Display Value (B CH.)	Press $\triangleleft \triangle \triangleright$ to show the current input B display value.	Input B Display Value

PROGRAMMING MODE OPERATING PROCEDURES

Block Charts	Display	Descriptions	Default
	Measuring Status	Present value for measurement.	
	Pass Code (P.Cod)	Press $\triangleleft \triangle \triangleright$ to enter pass code.	00000
		Pass code is correct that will enter to parameter groups. Pass code is wrong that will back to measuring status.	
	Math Type Setting (tYPE)	Press $\triangleleft \triangle \triangleright$ to select the math type of input A & input B; A ($\sqrt{\text{A}}$), A (Abs.A), A+B (Add.Ab), A-B (Sub.Ab), AXB (MUL.Ab), A/B (div.Ab), A&BHi (And.Hi), A&BLo (And.Lo).	59rA
	Decimal Point Setting (dP)	Press $\triangleleft \triangle \triangleright$ to select decimal point (0, 1, 2, 3, 4) EX: if the value shows "0.00" that means the decimal point is 2 digits.	00000
	Input A Display Low Scale (AdSPL) Setting	Press $\triangleleft \triangle \triangleright$ to modify display low scale for the input signal zero value. EX: If the input signal is 4~20mA; 4mA is shown display 0.00, this parameter must be set for 000.00.	Customers specify
	Input A Display Hi Scale Setting (AdSPH)	Press $\triangleleft \triangle \triangleright$ to modify display high scale for the input signal span value. EX: If the input signal is 4~20mA; 20mA is shown display 100.00, this parameter must be set for 100.00.	Customers specify
	Input B Display Low Scale Setting (BdSPL)	Press $\triangleleft \triangle \triangleright$ to modify display low scale for the input signal zero value. EX: If the input signal is 4~20mA; 4mA is shown display 0.00, this parameter must be set for 000.00.	Customers specify
	Input B Display Hi Scale Setting (BdSPH)	Press $\triangleleft \triangle \triangleright$ to modify display high scale for the input signal span value. EX: If the input signal is 4~20mA; 20mA is shown display 100.00, this parameter must be set for 100.00.	Customers specify
	Display Average Setting (AvG)	Press $\triangleleft \triangle \triangleright$ to modify display average (1~99). PS: Please use this function for stable display value when input signal is unstable.	00005
	Display Low Cut Setting (LCUt)	Press $\triangleleft \triangle \triangleright$ to modify display low cut to 0 (0~99).	00000
	A/O Polarity Setting (PoOLAr)	Press $\triangleleft \triangle \triangleright$ to modify output is positive pole or negative pole. PS: Voltage output, NO: positive pole output (0~+10V) YES: positive & negative pole output (-10~+10V)	no
	A/O Low Scale Setting (AnLo)	Press $\triangleleft \triangle \triangleright$ to adjust A/O low scale to correspond to the display value. EX: A/O is 0~10V, the display is 10.0 to output 0V, this value must be set for 10.0.	00000
	A/O Hi Scale Setting (AnHi)	Press $\triangleleft \triangle \triangleright$ to adjust A/O hi scale to correspond to the display value. EX: A/O is 0~10V, the display is 90.0 to output 10V, this value must be set for 90.0.	99999
	Pass Code Setting (CodE)	Press $\triangleleft \triangle \triangleright$ to modify pass code (0~19999). PS: Please don't forget the new pass code after modification.	00000
	Key Lock Setting (LoCK)	Press $\triangleleft \triangle \triangleright$ to lock the keys, using key lock function only can view the parameters, but cannot modify any values. PS: no (unlock), YES ("ENT" unlock, others lock).	no

Error Code of Self-Diagnosis

Display	Descriptions	Display	Descriptions
1 oFL	Input signal is over 120% of input range.	doFL	Math operating result is over display range (19999).
-1 oFL	Input signal is under -20% of input range.	-doFL	Math operating result is under display range (-19999).
RoFL	Input signal A is over display range (19999).	boFL	Input signal B is over display range (19999).
-RoFL	Input signal A is under display range (-19999).	-boFL	Input signal B is under display range (-19999).
AdEr	Input signal is over 180% of input range or meter error.	E-00	EEPROM reading/writing suffers the interference (about 1 million times).

**Please check the wiring connection is correct first, if the problem still exist, please return the meter to the factory.

CALIBRATION OPERATING PROCEDURES

Display	Descriptions	Default
<pre> graph TD A[10000] -- "Press ENT & ← together for 3 sec" --> B[1 nLo1] B -- "Press ENT" --> C[1 nHi1] C -- "Press ENT" --> D[1 nLo2] D -- "Press ENT" --> E[1 nHi2] E -- "Press ENT & → together for 3 sec" --> F[545] </pre>	Measuring Status Present value for measurement Press ENT & together for 3 sec will enter to calibration operating procedures. Input Low Scale 1 Calibration (inLo1) 1. Input standard low scale signal to input 1. 2. Press > to calibrate input low scale. Input Hi Scale 1 Calibration (inHi1) 1. Input standard hi scale signal to input 1. 2. Press > to calibrate input hi scale. Input Low Scale 2 Calibration (inLo2) 1. Input standard low scale signal to input 2. 2. Press > to calibrate input low scale. Input Hi Scale 2 Calibration (inHi2) 1. Input standard hi scale signal to input 2. 2. Press > to calibrate input hi scale. System Setting Page (SYS) 1. Finish calibration operating procedures will enter to system setting group. 2. Press & together to back to measuring status.	

Warning: Calibration of this meter requires a standard signal with 0.01% accuracy or better and an external meter with 0.005% accuracy or better.